




80x80mm



Instructional Manual smart camera

Powered by **tuya**

- Bitte scannen Sie den QR-Code, um das deutsche Handbuch, das Installationsvideo und die Funktionseinführung zu erhalten
- Escanee el código QR para obtener el manual en español, el video de instalación y la introducción de la función
- Veillez scanner le code QR pour obtenir le manuel en français, la vidéo d'installation et l'introduction des fonctions
- Отсканируйте QR-код, чтобы получить руководство на русском языке, видео по установке и описание функций
- Scansionare il codice QR per ottenere il manuale in italiano, il video di installazione e la guida alle funzionalità. Video di installazione e funzionalità
- Leia o código QR para obter o manual em português, o vídeo de instalação e a introdução das funções
- Zeskanuj kod QR, aby uzyskać instrukcje, filmy instalacyjne i funkcje
- من فضلك قم بمسح رمز الإستجابة السريعة (QR-code) ، حصول على دليل المستخدم باللغة العربية وفديو التثبيت ووصف للوقت

請掃描二維碼獲取中文的說明書、安裝視頻及功能介紹

Basic Parameters

Product Name: Smart Camera
 Pixel: 2.0MP/3.0MP/4.0MP
 Video Compression: H.264 H.265 High Profile
 Image Enhancement: Digital Wide Dynamic 3D Noise Reduction
 Local Storage: MicroTF card
 Wireless Encryption: WEP/WPA/WPA2 Encryption
 Power Input: 5V 1A(Min)
 Total Power Consumption: 5W (Max)
 WirelessStandard: 2.4G 802.11 b/g/n
 Support Platform: Android/iOS

Component Description:


Reset Button: Long press "reset" hole 5sec, reset success.

It is recommended to insert 8-128GB high-speed Micro TF card, otherwise it will not be able to store, view historical video and support Important functions such as firmware upgrading.

Packing list: Smart Camera x 1, Manual x 1, USB Power Cord x 1, Power Adapter x 1, Screw Accessories Package x 1

Smart Life APP Instructions

1. Download Smart Life APP
 - Scan the QR code on the right to download the Smart Life APP. You can also search "Smart Life" in either App Store or Google Play to install the APP.




2. Register a Smart Life account and sign in the app
 - You will be prompted to enter your mobile number or email address to register. The system automatically recognises your country / area. You can also select your country code.

Note: If you use a Mobile number you will be sent a text message with your confirmation code to complete your account registration.


Add The Device-Scan QR code mode

- Make sure Wi-Fi is available and connected to the Internet.
- Connect the camera to the power, then system startup completed.
- Open "Smart Life" APP, press the '+' in the upper right corner of the main screen (Figure 01); choose "Security & Video Surveillance", click "Smart Camera" (Figure 02) to add camera; and then click "Next step" (Figure 03);




Please note that only 2.4 GH Wi-Fi network is supported;


- If the mobile phone is not connected to wi-fi, please click "Connect to Wi-fi" (Figure 04);
- It will jump to the WLAN interface and connects Wi-Fi (Figure 05). If the phone is connected to Wi-Fi (Figure 06) ;
- If the mobile phone is not connected to wi-fi, please click "Connect to Wi-fi" (Figure 04);
- It will jump to the WLAN interface and connects Wi-Fi (Figure 05). If the phone is connected to Wi-Fi (Figure 06) ;



- If the mobile phone is not connected to wi-fi, please click "Connect to Wi-fi" (Figure 04);
- It will jump to the WLAN interface and connects Wi-Fi (Figure 05). If the phone is connected to Wi-Fi (Figure 06) ;




- Connection completed (Figure 09), and click "Done";
- Then jump to preview interface (Figure 10)
- After closing the device preview interface, the interface returns to the APP home page. At this time, the connected device will appear on the APP home page (Figure 11). Then you can click directly to the device interface to see the monitoring situation without re-adding afterwards.




Add device-WIFI fast connection mode

- Select "EZ Mode" (Figure 12)
- Click Next (Figure 13)
- Enter the account and password that can connect to WIFI (Figure 14)



- Click to complete the connection (Figure 15)
- Video screen (Picture 16)



Matters Need Attention

Try to keep away from the metal space;
 Avoid the furniture , microwave oven blocked;
 Avoid the space where the audio, video and data lines are wound, and keep the space away from them as large as possible;
 Ensure that as close as possible to the coverage of wireless Wi-Fi signals. Switching network environment;
 In the new network environment, please press the reset hole about 5 seconds, then connect to the network.

The name and content of the harmful substances in the product

Part Name	Harmful Substance					
	Pb	Hg	Cd	Cr(VI)	PBB	PBDE
shell	○	○	○	○	○	○
Board	X	○	○	○	○	○
charger	○	○	○	○	○	○
annex	○	○	○	○	○	○

This form is based on the provisions of SJ/T 11364.

This product conforms to RoHS environmental protection requirements. At present, there is no mature technology in the world to replace or reduce the lead content in the electronic ceramics, porcelain, optical glass, steel and copper alloy.

SERVICE

Thank you for your trust and support to our products, we will provide you with a two-year worry-free after-sales service (freight is not included), please do not alter this warranty service card, to safeguard your legitimate rights and interests. If you need service or have any questions, please consult the distributor or contact us.


Product quality problems occur within 24 months from the date of receipt, please prepare the product and the packaging, applying for after-sales maintenance in the site or store where you purchase; if the product is damaged due to personal reasons, a certain amount of maintenance fee shall be charged for repair.

We have the right to refuse to provide warranty service if:

- Products with damaged appearance, missing LOGO or beyond the service term
- Products that are disassembled, injured, privately repaired, modified or have missing parts
- The circuit is burned or the data cable or power interface is damaged
- Products damaged by foreign matter intrusion (including but not limited to various forms of fluid, sand, dust, soot, etc.)

RECYCLING INFORMATION

All products marked with the symbol for separate collection of waste electrical and electronic equipment (WEEE Directive 2012/19 / EU) must be disposed of separately from unsorted municipal waste. To protect your health and the environment, this equipment must be disposed of at designated collection points for electrical and electronic equipment designated by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences for the environment and human health. To find out where these collection points are and how they work, contact the installer or your local authority.



WARRANTY CARD

Product Information

Product Name _____

Product Type _____

Purchase Date _____

Warranty Period _____

Dealer Information

Customer's Name _____

Customer Phone _____

Customer Address _____

Maintenance Records

Failure date	Cause Of Issue	Fault Content	Principal